
**MONTHLY INSPECTION AND MAINTENANCE CHECKLIST FOR AUTOMOTIVE LIFTS
SCHOOL DISTRICT NO. 85 (Vancouver Island North)**

The following is a quick reference checklist for an automotive lift inspection and maintenance.

Refer to the manufacturer's recommended inspection points and maintenance procedures for more information.

Location: _____

Make & Model: _____

GENERAL:

Good Bad Fixed (v)

- | | | | |
|--------------------------|--------------------------|--------------------------|---|
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Lift operators have been instructed in safe use and operation of lift. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Check accessibility of operating procedures, safety tips and generic safety material. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Check accessibility and readability of safety warning labels. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Check the readability of rated load capacity of the lift. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Examine structural components including welds. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Examine electrical components and wiring. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Check lift controls. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Check operation of positive stop and lift locks. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Check all points requiring lubrication. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Check exposed surfaces and edges for burrs or sharp edges. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Check all fastening devices for tightness including floor anchor bolts. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Lift components are free of debris and foreign materials. |

TELESCOPING LIFT PADS (used mainly on frame-contact lifts):

- | | | | |
|--------------------------|--------------------------|--------------------------|---|
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Check over travel stops for wear. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Watch for stress cracks or breaks in welds and castings examine arms for permanent bending. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Lubricate swivel points and extendable parts of carrying arms. |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Inspect lift adapters and extenders. |
-

